

Supervision of Plasma-Etch-Processes at different Tool Types

Volker Tegeder

Infineon Technologies SC300

Supervision of Plasma Etch Processes at different Tool Types

Overview

- **European Project: APC300**
 - **Sensor Integration**
 - different chamber types
 - B-field variations
 - **Linking logistical Data**
 - spy for logistical data
 - innovative tool/sensor interface
 - **Application Examples of SEERS in Production**
 - automatic Fault Detection
 - tool start-up / Tool release
 - chamber conditioning
 - influence of preprocesses
-

European Project: APC300

Supervision of Plasma Etch Process by SEERS



Assessment Site of Hercules/APC System

Infineon Technologies SC300 (Dresden)

Participants

AMD Saxony

ASI (Berlin)


Infineon Technologies (Regensburg)

ST Microelectronics (Rousset, France)

Start: 1st February 2000

Duration: 18 Month

Control System Set Up



Evaluation site

focus on

- process control
- economical benefit



- 100% supervision on monitored etch processes
- up to 12 chambers
- approx. full POR
- link to logistical data
- different processes
 - poly / metal / oxide
- different chamber types
 - capacitive / ICP

Participants


- different applications at single tools
- mutual exchange of results

Sensor Integration


SEERS Measurement Principle



n: Electron density
v: Collision Rate



Adaptation to different chamber types



DPS

- peak voltage
- inductively coupled
- capacitive \neq inductive coupled frequency

LAM 300

- peak voltage
- inductively coupled
- special software interface

eMxP+

- peak voltage
- rotating B-field
- optical access for OES

Never stop thinking

Synchronization to rotating B-Field

installed B-field sensor

Chamber wall

90°

Vacuum

OES connection

Hercules sensor with SMA connector

B-field impacts plasma
 => varying SEERS signal
 => synchronization necessary

B-field sensor at chamber wall

B-field and trigger signal

eMXP300: B-field Signal

U [V]

t [s]

Never stop thinking

Linking Sensor Data to logistical Data

Linking Sensor Data to logistical Data

Logistical data the missing link?!

Product #, lot #, recipe...important for any sensor:

Data Analysis

- correlation to in-line/electrical data
- economical benefit


Fault detection

- depending on product
- depending on recipe

Link I : Spy for logistical Data

Link II : Innovative tool sensor interface

SPY for logistical Data




- ABAKUS SECSII SPY**
- full passive system
 - configurable message filter
 - communication to sensor via SECSII
 - ethernet based
- (patent pending)



Innovative Tool / Sensor Interface

Example: SEERS




LAM Plug and Play Interface

- universal sensor data interface
- independent network ethernet based 10 Mbit
- access to logistical data
- merging tool and sensor data => the virtual tool



Application Examples of SEERS in Production

Automatic Fault Detection



Average curve from 80 individual M1 runs.


Different fault detection methods possible. First: average value of v , n

SEERS sensitive to

- pressure
- magnetic field
- RF- power
- chemistry
- chamber condition
- pre-processes
- etched substrate
- arcing

SEERS Fingerprint

Automatic Fault Detection



Arcing Traces in Chamber \Rightarrow Exchange of E-Chuck and Ion Shield

Fault detected by lot-average of v

Never stop thinking

Tool start up / Tool release

Checking Chamber Condition with SEERS

Define reference recipe



Determine process fingerprint

Perform Tests for

- HW change
- tool hook up



Tool start up / Tool release



Arcing traces at gas distribution

Recipe

Step 1

25mtorr /
215W / 30G/
50 sccm O₂


Step 2

25mtorr / 215W
0 G / 50sccm O₂



Chamber Conditioning

(after idle chamber)




- ## First wafer effect
- same chamber
 - approx. 1h idle
 - different gasses
 - $P_{G/D}$ proportion 1:2
 - $t_{G/D}$ proportion 1:2,2
 - $p_{G/D}$ proportion 1:2,5

similar warm up curve with strongly different recipes
 => thermic effect expected

Comparison with different recipes

Chamber Conditioning (after wet clean)



Conditioning procedure I

- resist wafers
- poly wafers
- particle test
- etch-rate test

acceptable particle level after > 50 wafers
=> long and costly procedure




Lesson learned: minimal collision rate correlates with particle count

Usual procedure with resist and poly wafers

Never stop thinking

Chamber Conditioning (after wet clean)

Never stop thinking




- Conditioning procedure II**
- oxide wafer for low collision rate
 - patterned wafers
 - constant collision rate
 - particle test



Collision Rate rises as poly is etched
- still not perfect conditioning

Chamber Conditioning (after wet clean)

Never stop thinking



Conditioning procedure III


- resist wafers
- oxide wafers (unpatterned)
- particle test



Only 10 wafers for conditioning compared to prior 50!

Optimized procedure with resist and oxide wafers

Influence of Pre-Processes



GC MO Process


- stable level for ν at 10^6 s^{-1}
- P3 pre-process highest impact

Process mix at one chamber

Collision rate with different pre-processes

Dr. Volker Tegerer
AEC/APC-Symposium XII 24.-28.9.00

Influence of Pre-Processes



GC-Etch


- Multi-Process-Chamber
- Preprocess indicated
- P3 has highest impact
- P1 compensates P3 impact

P3: strongly polymerizing process
P1: strongly etching of polymers

Process mix impact on product

Never stop thinking

Influence of Pre-Processes



- *LOT*
- *GC BIAS*
- *other electr. data*

**Data Mining:
Decision Tree**

- based on statistics
- suitable for high data volume
- detects correlation

Target for decision tree: Plasma Collision Rate ν

⇒ Correlation: Collision Rate / GC BIAS for special Lots with high collision rate

Co-Authors

Matthias Scholze
Torsten Prescher
Uta Federbusch
Thomas Bauer
Eckhard Marx

Infineon Technologies SC300
Infineon Technologies SC300
Infineon Technologies SC300
Infineon Technologies SC300
Infineon Technologies SC300

Ute Nehring

Infineon Technologies Dresden

Daniel Zschäbitz
Mark Laqua

University of Dresden
University of Dresden

Mathias Hofmann
Sven Mueller

AMD Saxony
AMD Saxony

Robert Ronchi
Michel Derie

ST Microelectronics Rousset, France
ST Microelectronics Rousset, France

Acknowledgement:

*The presented work is funded by the European IST program 4-8-3
on the SEA-Initiative*

Dr. Volker Tegerer
AEC/APC-Symposium XII 24.-28.9.00