

Application of electrical plasma measurement techniques at Advanced Process Control

Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden

Andreas Steinbach
Center for
Development and Innovation
Infineon Technologies Dresden

andreas.steinbach@infineon.com

www.infineon.com



**Project
PULSAR**

Acknowledgement

CDI

- The author of this presentation would like to thank:
 - Ute Nehring
Lars Christoph
Siegfried Bernhard
Infineon Technologies Dresden, Germany
 - Thomas Dittkrist Thomas Werner Christoph Steuer
Harald Wendel Sören Mothes
University of Technology Dresden, Germany
 - Michael Hartenberger
University of Technology Cottbus, Germany
- The work for this paper was supported:
 - by the EFRE fund of the **European Community**
 - and by funding of the **State Saxony** of the Federal Republic of Germany, project **PULSAR**, project number 5706.
- The authors are responsible for the content of the paper.

Outline

CDI

- Motivation –
Why do we need electrical plasma measurement techniques ?
- Electrical plasma measurement techniques
 - „Classical“ electrical measurement techniques
 - Impulse detection in RF field
 - Self Excited Electron Plasma Resonance Spectroscopy
- Application of electrical plasma measurement techniques for APC
 - Data compression
 - Complex process parameters - Benefit for APC
- Summary



**Project
PULSAR**



Established and new measurement techniques – a historical comparison

CDI

□ Astronomy →

Optical methods

- Widely used for some hundred years now
- Familiar to every astronomer
- Useful, great results
- But they use only a small wavelength window

□ New methods last century

- Using other regions of the electromagnetic spectra
- Offer additional information
- Examples:
UV- and IR-, X-Ray- and
Radio astronomy

□ Plasma processing →

Optical methods

- Widely used, e.g., OES and interferometry
- Familiar to every engineer
- Useful, e.g. endpoint
- But they use only a small wavelength window

□ New methods in recent years

- Using other regions of the electromagnetic spectra
- Offer additional information
- Examples:
Radio Frequency measurement and SEERS

Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden

APC

Project
PULSAR

01.03.2001
Page 4



Why do we need „electrical“ plasma measurement techniques ?

CDI

- The plasma we use is:
 - A non- equilibrium plasma
 - Driven electrically by RF power
 - Excited by electron collisions with neutrals mainly
- So, if we use an „electrical“ plasma, we should use „electrical“ methods for plasma processes monitoring too !
- Well-know measurement techniques:
 - RF power, forward and reflected
 - RF peak voltage
 - Impedance
 - DC bias voltage
- New methods:
 - Impulse detection in RF field
 - Plasma parameter measurement by **Self Excited Electron Resonance Spectroscopy - SEERS**

„Classical“ well-known measurement techniques

„Classical“ electrical measurement techniques



CDI

- DC bias voltage:
 - Simple principle – difficult to realize
 - Dark space voltage at cathode mainly on wafer surface → DC bias plugs necessary → rarely used
- RF peak voltage:
 - Simple principle, capacitive measurement at the RF matchbox output
 - Should be available in all RF matches !
- RF power, forward and reflected:
 - **Still standard:** Between RF generator output and RF matchbox input
Power losses in RF match ! → RF power input to chamber unknown
 - **Where it should be measured:** At the RF match output !
New tools available now → see exhibition
- Plasma impedance:
 - Available with new tools at the RF match output → see exhibition too



Example of DC bias voltage: Arcing detection at Via etch in AMAT MxP

CDI

- DC bias peaks indicate arcing
- Recorded with simple x,t- recorder



Heavy Arcing



Al particle
on wafer

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden

APC

Project
PULSAR




01.03.2001
Page 8



Example of RF reflected power: Ion shield burning (heavy arcing) in AMAT MxP → Poster P206

CDI

- ❑ Spikes at reflected RF power indicate upcoming heavy arcing early
- ❑ Recorded with TadiGuard Process and Equipment Enhancer
- ❑ For details see Poster P206



Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden




Project
PULSAR

01.03.2001
Page 9



Example of RF power (at generator output): Comparison of 4 different RF matchboxes

CDI



- ❑ Recipe, e.g. RF generator power output is kept constant
- ❑ But, power dissipation in the chamber differs about 25 ... 30%, as indicated by bulk power measurement using HERCULES
- ❑ RF power measurement at RF generator output guarantees power maximum in the chamber of that configuration only, nothing else !

Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden

APC

Project
PULSAR


01.03.2001
Page 10



Impulse detection in RF field

Measurement principle of RF impulse detector

CDI




$$n(\omega) := \sqrt{1 - \frac{\omega_e^2}{\omega^2}}$$


$$E(x, \omega) := E_0 e^{2\pi i \cdot \frac{x}{\lambda(\omega)} - \tau(\omega)}$$

$$\omega_e := 2\pi \cdot 5001 \text{ G}$$

$$\lambda(\omega) := \frac{c}{\omega} \cdot 2\pi$$



Antenna at side window



Antenna at water tube

- ❑ Short **local** discharge →
 - Variation of **global** plasma impedance
 - Mismatch of RF match
 - Insufficient power adjustment
 - Short breakdown of global RF stray field
 - Measurement of field strength breakdowns outside of the chamber, wherever electromagnetic field of plasma is detected
- ❑ No direct measurement of „arcing waves“ (see Eccles Equation)

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden


APC

Project PULSAR

Basic scheme of RF impulse detector

→ Poster P104

CDI



- ❑ Time resolution 1 μ s
- ❑ Real-time signal compression by digital signal processor
- ❑ Individual calibration on every chamber and for every process, impulse classification
- ❑ For details see Poster P104



Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden

APC

Project
PULSAR

01.03.2001
Page 13




RF impulse detector: Detection of scratch at chamber wall in AMAT MxP chamber



CDI

Time resolved signals



- ❑ Scratch at chamber wall detected, but no impact on particle density
- ❑ Reliable correlation to particle density on wafer (= Arcing from production point of view) not possible

Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden



Project
PULSAR


01.03.2001
Page 14



RF impulse detector: Ion shield burning at Applied Materials MxP chamber



CDI



RF stray field impulses indicate ion shield burning (heavy arcing !)

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden



**Project
PULSAR**

01.03.2001
Page 15



Plasma parameter measurement using **Self Excited Electron Plasma Resonance Spectroscopy**

Principle of SEERS


CDI

RF current
RF voltage

FFT

Model SEERS

Electron collision rate
Electron density
Bulk power
DC bias voltage



- Self Excited Electron Plasma Resonance Spectroscopy
 - Passive electrical method
 - Integral physical parameters



Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden

APC

Project
PULSAR

Plasma parameter: Tool comparison at GC etch in LAM TCP

CDI



- ❑ Typical problem: Nominal identical chambers and same recipe. But process result of one chamber is different to all others ! Why ?
- ❑ ➔ Reason found by electron density: Significant different power dissipation, caused by TCP top power coupling into chamber

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden


APC

**Project
PULSAR**



Plasma Parameter: Product interaction DRAM – Logic at GC etch in LAM TCP → Poster P204

CDI



DRAM products destabilize chamber conditions

Logic Products stabilize chamber conditions

- Typical problem: Mix of many products in a chamber
 - Most products (here DRAM) show stable electrical results all the time
 - Few products (here one Logic product) show drift of electrical product parameters, e.g. depending on process mix and RF hours
- → Electron collision rate indicates impact of DRAM and Logic products on chamber conditioning. For details see Poster P204

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden



Project
PULSAR

01.03.2001
Page 19





Plasma Parameter: Optimization of dry clean at STI etch in AMAT MxP

→ Poster P205



CDI



- Typical task: Optimization of conditioning or dry clean processes
 - Usually done: By experience and trial & error, efforts consuming
 - Cleverly done: By additional measurement of process parameters
- Electron collision rate measures first wafer effects, caused by clean
 - Dry clean 1: first wafer effect on 2 ... 4 following resist dummies
 - Dry clean 2: first wafer effect on 1 following resist dummy only
- For details see Poster P205

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden



Project
PULSAR

01.03.2001
Page 20



Application of electrical plasma measurement techniques for APC

Data compression - an essential need for APC in high-volume production

→ **Poster P208**


CDI

- APC in high-volume production → very large amounts of data
- How to compress data ? By use of
 - Smart „Intelligent“ sensors with real-time data compression
 - Calculation of statistical key numbers from raw data
 - Model-based data analysis, for details **see Poster P208**
 - Physical and chemical models, no blind statistics !
 - **Complex process parameters, depending on tool- and wafer impacts –
better to watch 2 relevant than all available parameters daily !**
- Data compression for daily use by two steps:
 - 1st step:
A complex process parameter indicates, that something might be wrong
 - 2nd step:
Use of other tool- and process parameters to find in detail, what is wrong



Example of complex process parameter: Electron collision rate

GC Stack etch at LAM TCP, main etch: Effect Pareto for electron collision rate



Real power
dissipation in the
chamber

Real particle
density in plasma


Real gas mixture
in chamber

- ❑ Electron collision rate depends on parameters, which can be measured
- ❑ Electron collision rate depends also on parameters, which cannot be measured directly (chamber drift = impact of date)


Application of plasma parameters for process monitoring at GC etch at LAM TCP



CDI



- GC etch in LAM TCP
- Electron collision rate indicates stability of electrical product parameter (Example: Gate Conductor width of a logic product)



t_0 - Introduction of process mix change (chamber used for Logic mainly)

Andreas Steinbach
Center for
Development and
Innovation
Infineon
Technologies
Dresden



Project
PULSAR


01.03.2001
Page 24



Correlation between plasma parameters and electrical product parameters

→ **Poster P208**

CDI



□ DRAM:


- Large process window at GC etch
- → stable electrical results on product
- → no correlation process parameter – product parameter



□ Logic product::

- Small process window at GC etch
- → unstable electrical results on product
- → correlation process parameter – product parameter

electron collision rate



Andreas Steinbach
Center for
Development and
Innovation

Infineon
Technologies
Dresden

APC

**Project
PULSAR**

01.03.2001
Page 25



Lessons learned: AEC and APC

CDI

- ❑ Equipment Control and Process Control
 - Are "two pairs of shoes"
 - The process can go wrong, while the available tool parameters are stable
- ❑ Equipment (Tool) Control
 - By process parameters, as a first indicator
 - And tool parameters, to find reasons of tool problems in detail
- ❑ Process Control
 - Demands sensitive, complex process parameters
 - Simple correlation between tool parameter and results on product ?
➔ use another tool !
 - Correlations between process parameters and electrical results are necessary for product-related alarm limits
 - Product engineering accepts only one or very few key numbers per process ➔ data compression



Lessons learned: Data compression and analysis

CDI

- ❑ Data compression for APC
 - Complexity of electrical parameters, measured on plasma processes is a data compression itself → data compression „by physics“.
- ❑ Correlations to product parameters have to be done separately for:
 - Wafers
 - Process steps
 - Products
- ❑ Use of reasonable statistical methods **and** technological knowledge, to reduce data amount
- ❑ You won't find any correlation between measured parameters:
 - If the measured parameters are not really sensitive to process drift
 - In case the process is stable (see DRAM on Poster P208)
- ❑ In both cases best statistical methods won't find any correlation.



- Electrical plasma measurement techniques
 - Open a new window for plasma monitoring, additional information
 - Measure sensitive process parameters, tool **and** wafer impacts
 - Integral values, no local measurements usually
 - In real time
- Application for process engineering and maintenance
 - Fault detection of process and tool
 - Process development and optimization
- Application for process integration and product engineering
 - Monitoring of process drifts, product interactions **in real time**
 - Complex process parameters supplement of in-line data for product engineering
 - Bridge between process engineering and product engineering
- electrical plasma measurement techniques are an intelligent way of data compression „by physics“.