

Application of the Plasma Monitoring System HERCULES on process monitoring of oxide etch at Applied Materials MxP+ chamber

A. Steinbach	Infineon Technologies Dresden
S. Bernhard	Infineon Technologies Dresden
M. Sussiek	Technische Universität Hamburg - Harburg
C. Steuer	Technische Universität Dresden

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer

08.06.1999

Page 1

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Introduction

Contents

- **Theory and setup**
- **Basic experiments**
- **Results of long term process
and tool monitoring**
- **Summary and outlook**

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer

08.06.1999


Page 2

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Introduction

Basic Model of HERCULES

Self Excited Electron Plasma Resonance Spectroscopy



A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer

08.06.1999

Page 3

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Theory and Setup

Measurement principle of HERCULES

rf current
rf voltage




FFT



Model
SEERS



Electron collision rate
Electron density
Bulk power
DC bias voltage



- **Passive** electrical method,
no impact on the plasma
- **Integral** measurement

SEERS provides reciprocally averaged parameters

Electron density :

$$\tilde{n} = \left(\frac{1}{V} \int_V n_e^{-1} dV \right)^{-1}$$



Electron collision rate:

$$\tilde{\nu} = \frac{\tilde{n}}{V} \int_V \frac{\nu}{n} dV$$

Bulk power:

$$P_B \propto \frac{\tilde{\nu}}{\tilde{n}} \sum_k |I^{(k)}|^2$$

HERCULES Equipment Setup



**Sensor surface:
anodized
aluminum, similar
to chamber wall.**

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer


08.06.1999

Page 6

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany


Theory and Setup

Correlation between plasma parameters and process parameters: Contact etch at MxP+





Variation of “chemical” process parameters, e.g., flow of reactive gases → often strong nonlinear effects

Variation of “physical” process parameters, e.g., pressure, rf power → monotonous response, mainly linear correlations




Correlations between electron density and gas flows: Contact etch an MxP+



CF₄, CHF₃, Ar, O₂ chemistry: CF₄- or CHF₃- flow increases
 → higher F- concentration
 → electron density decreases

Correlations between plasma parameters and etch results: Contact etch at MxP+



Increasing CHF_3 - flow:


$\text{F} \nearrow \rightarrow$ oxide etch rate on blank wafers $\nearrow$

$\text{CHF}_x \nearrow \rightarrow$ higher side wall passivation on structure wafers, contact angle $\searrow$

Increasing CF_4 - flow: F , $\text{CF}_2 \nearrow$

$\rightarrow$ oxide etch rate on blank wafers $\nearrow$

$\rightarrow$ lower side wall passivation on structure wafers. contact angle $\nearrow$



Three examples of long term process monitoring

- Three examples of process and tool monitoring results are shown now.
- Monitoring of Contact etch process at an Applied Materials MxP+ chamber.
- Monitoring of the same chamber for 14 months.
- Monitoring of three processes.

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer


08.06.1999

Page 10

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Process & Tool Monitoring

Conditioning effects on long term process stability




Step	Pr 1	Pr 2
pre	--	N ₂ / O ₂ step
main	BPSG etch	BPSG etch
over	--	Nitride etch

Process 2:
deconditioning caused by pre step and over step.

Electron collision rate is very sensitive to etch chemistry.

Contact etch at AMAT MxP+
Process monitoring of 3 products covering the period between two wet cleans.


Short term chamber drift and first wafer effect



Contact etch at AMAT MxP+
Process monitoring of 3 lots of one product.

- Electron collision rate shows dependence on chamber idle time.
- “First wafer effect”: Constant chamber conditions after about 12 wafers !
- Expected reasons: Temperature equilibrium and gas adsorption at liner wall.


Tool related effects on long term process stability



- Wet clean (WC) depending drift effect, hardware reason (not found yet):
 - **WC1, WC3** chamber drift
 - **WC2, WC4, WC5** stable chamber conditions on varying level

Contact etch at AMAT MxP+
 Process monitoring of product wafers of one product for 5 wet clean cycles, more than 6 months.

Open area impact on plasma parameters



- One recipe for two products.

Product 1

Product 2


- Impact of open area on electron density.

Contact etch at AMAT MxP+
Process monitoring of product wafers of one product for 5 wet clean cycles, more than 6 months.

Summary of the 1st process monitoring example

- Conditioning effect
- “First wafer” effect: Temperature drift & gas adsorption
- Impact of chamber kit and wet clean procedure
- Impact of open area
- But no impact of all these variations on yield.
- The monitoring system can detect small process variations, which can still be neglected by that product.
- This should be the normal situation, the process runs well !


Single wafer control of process stability




Contact etch at AMAT MxP+, single wafer process monitoring lot by lot

Sometime in 1998:
Process o.k.

3 months later:
Process problem !




6 months later:
Process o.k. again




Wafer mean values of plasma parameters indicate wafer depending process variations of one product.

Time resolved results of single wafer control




Sometime in 1998:
Process o.k.

3 months later:
Process problem !



6 months later:
Process o.k. again



Contact etch at AMAT
MxP+, time resolved
single wafer monitoring

Time resolved values of plasma
parameters show process
instability of one product in detail.

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer





08.06.1999

Page 17

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Process & Tool Monitoring 2nd example

Correlation between plasma parameters, failures at electrical component test & yield




- Correlation between standard deviations of plasma parameters, electrical failure counts and yield.
- Process problem impacts all chambers, used for Contact etch.
- Process problem increases tool related differences between chambers.

Summary of the 2nd process monitoring example

- Plasma parameter standard deviations of one product correlate with electrical failure counts and yield loss.
- Electron collision rate and electron density at Contact etch indicate process problems at a pre- process of this one product.
- A serious process problem was indicated in real time by plasma monitoring with Hercules.


Real time detection of hardware failure




Increase of mean values of plasma parameters on all products indicate a hardware failure at the chamber.

Contact etch at AMAT MxP+

Oxide etch rate measurement on blank test wafers **does not show** any significant variation.




Comparison between mean and standard deviation of plasma parameters




Standard deviation shows higher sensitivity to process instability.



Contact etch at AMAT MxP+



Hercules detects arcing inside He feedthrough of Applied Materials MxP+ chamber



Contact etch at
AMAT MxP+



Process instability was caused by
Arcing inside He feedthrough.

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer

08.06.1999

Page 22

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Process & Tool Monitoring 3rd example

Summary of the 3rd process monitoring example

- Plasma parameter standard deviations of all kinds of wafers indicate tool problem.
- Plasma parameters are much more sensitive as etch rate test on blanket oxide wafers.
- Arcing inside He feedthrough has been detected in real time, immediately.
- Early tool failure detection allows preventive maintenance measures and prevents yield loss.

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer

08.06.1999

Page 23

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Process & Tool Monitoring Summary

Summary

- Hercules has been used for long term process and tool monitoring.
- The plasma parameters are real process parameters. They depend on tool conditions and wafer impacts.
- Therefore plasma parameters can be used for detection of tool related problems as well as wafer related effects.

A. Steinbach
S. Bernhard
M. Sussiek
C. Steuer

08.06.1999

Page 24

Workshop on Self Excited Electron Plasma Resonance Spectroscopy
8. - 9. June 1999 at Infineon Technologies Dresden, Germany

Summary